

## **Frequently asked questions regarding the use of the [TM30 Coin Timers](#)**

**Is the TM30 suitable for Instantaneous showers?** Check the power of the shower. The TM30 is only good for up to 7kW. Over 7kW you will need to fit a contactor, see your electrician or local electrical wholesaler for this.

The TM30 has no IP rating and should not be mounted in the splash zone.

**Is the TIM30 suitable for Washing Machines?** It depends on your washing machine. We always recommend you to set the timer to cover your longest cycle (usually about 75mins). Some washing machines have a safety feature to stop the door being opened if the machine is still mid-cycle, if the timer switches the machine off prematurely the door can be opened with quite a messy result.  
**Check your longest cycle!!**

**"During a snooker game, some of our members like to go to the bar or use the toilet. Is there a facility within to pause the timer while this happens?"** Yes there is a 'credit hold' facility fitted as standard.

**What is MultiCoin?** The TM30 has not got multi-coin facilities: With multi-coin the timer waits for a preset value to be entered before switching.  
e.g. If you wanted to set the price of a sun-bed at £2.40 for 30mins the TM30 would switch after the first coin is entered whereas the TM3100 would wait for the full amount to be entered before switching.

### **SPECIFICATION**

**Input voltage:** 240V AC

**Switching capacity (at 240V AC):** 7000 VA

**Power consumption:** 22 Watts maximum

**Dimensions:** Height - 270mm, Width - 183mm, Depth - 93mm

**Weight:** 1.4 Kg

**Case material:** High impact ABS

**Standards conform to:** BSEN 60730-1:1992 & part 2.7 of that standard. 1989 EMC Directive:  
General Standards: EN50081-1, EN50082-1